



**RTC Manufacturing, Inc**

P.O. Box 150189  
Arlington, TX 76015  
(800) 782-8721  
(817) 274-3610 fax

## MASTER GROUP SWITCH SETTING

### Master Group Switch Setting Instructions

The Master Group Switch allows the user to increase the number of Group Addresses (99) and Location Addresses (99) in the CPR 2102 system. Each Group with 99 Addresses and 99 Location Addresses is a Master Group. The Master Group Switch allows the user to select Master Groups by setting switch positions 0-9.

Master Group	Switch Position
1	0
2	1
3	2
4	3
5	4
6	5
7	6
8	7
9	8
10	9



The Main Screen of the CPR central office software has a drop down menu of Master Groups 1 through 10. The entering of data into a specific Master Group, Group Address and Location Address at the central office and the setting of the field CPR unit rotary Master Group Switch, Group Address and Location Address DIP switches makes a unique CPR address for the school zone location.

Master Group Diode  
Jumper Selection

8	4	2	1
○	○	○	○
○	○	○	○

Master Group	Diode Position
1	0
2	1
3	2
4	3 (1 + 2)
5	4
6	5 (1 + 4)
7	6 (2 + 4)
8	7 (1 + 2 + 4)
9	8
10	9 (1 + 8)