



RTC Manufacturing, Inc.

P. O. Box 150189
Arlington, TX 76015

(800) 782-8721
(817) 274-3610 fax

Model TR-3 / TR-4
GPS Time Reference

Application Note Number 14

Setup Instructions for the TR-3 / TR-4 GPS Time Reference
for

2070N / GARDNER

From the Main Menu select:

#4-CABINET / BASIC NEMA / INCHAN / CHAN69 / FCTNTYPE=TIMSET /
FCTNINDX=1 / UNIT=1 / CONN/BIU=A / PIN=AA / CHANIN1=0 / CHANIN2=0 /
LOGIC=AND

#7 COORD / BESTWAY / SYNCTIME=4:00 / CORDMOD=BEST / MAX DWELL=15

Connect the TR-3 / TR-4 relay common wire to logic ground and the normally open wire to pin AA of the "A" connector which is the Clock Reset function.

Set the switches on the TR-3 / TR-4 for a time reset at 4:00AM, Everyday (EDY) per the TR-3 / TR-4 programming instructions.

DISCLAIMER:

The information contained in this application note is accurate to the best of our knowledge. It is the responsibility of the end user to determine the method of resetting the time of day on the exact model and firmware version of the controller being used.