



RTC Manufacturing, Inc.

P. O. Box 150189
Arlington, TX 76015

(800) 782-8721
(817) 274-3610 fax

Model TR-3 / TR-4
GPS Time Reference

Application Note Number 6

Setup Instructions for the TR-3 / TR-4 GPS Time Reference
for

ECONOLITE

Pin 14 of the "D" connector is the Time Reset function.

Connect the TR-3 / TR-4 relay common wire to logic ground and the normally open wire to pin 14 of the "D" connector which is the Time Reset function.

Set the switches on the TR-3 / TR-4 for a time reset at 3:30AM, Everyday (EDY) per the TR-3 / TR-4 programming instructions.

The controller is preprogrammed to set its clock to 3:30AM when logic ground is applied to pin 14 of the "D" connector.

DISCLAIMER:

The information contained in this application note is accurate to the best of our knowledge. It is the responsibility of the end user to determine the method of resetting the time of day on the exact model and firmware version of the controller being used.